


# KL 92 4.5mm SCHEMATIC



Magazine set

| NO       | DESCRIPTION            |
|----------|------------------------|
| A1-45    | Magazine Lip           |
| A2       | Air Nozzle Rubber      |
| A9 / A12 | Pin                    |
| A10-45   | Magazine Spring        |
| A11-45   | Magazine Bar           |
| A13-45   | CO2 Magazine Frame     |
| A14-45   | Magazine Frame Stopper |
| A15      | Screw                  |
| A16      | CO2 Magazine Valve     |
| A17      | Cartridge Stab         |
| A18      | Cartridge Base Cover   |
| A19      | Magazine Bottom        |

Air Nozzle set

| NO      | DESCRIPTION       |
|---------|-------------------|
| M1-45   | Air Nozzle        |
| M2      | Air Valve Spring  |
| M3-45   | Air Valve         |
| M4      | Piston Ring       |
| M5      | Air Nozzle Spring |
| M6      | Piston            |
| M7 / M8 | CS / O Ring       |
| M9      | Cylinder Base     |
| M10     | Screw             |

| NO   | DESCRIPTION             |
|------|-------------------------|
| 1    | Outer Barrel            |
| 2    | Barrel Pin              |
| 3-45 | Inner Barrel            |
| 6    | Cushion                 |
| 7-45 | Hop Up Bucking          |
| 8-45 | Hop Up Chamber          |
| 10   | Barrel Lock             |
| 11   | Recoil Spring           |
| 12   | Recoil Spring Guide     |
| 13   | Slide                   |
| 14   | Safety Lever Lock       |
| 15   | Safety Lever - L        |
| 16   | Safety Lever R          |
| 17   | Safety Lever Bar        |
| 18   | Trigger Base            |
| 19   | Trigger Spring          |
| 20   | Trigger                 |
| 21   | Hammer lever            |
| 22   | Hammer lever Spring     |
| 23   | Hammer                  |
| 24   | Stop Plate              |
| 25   | Shear                   |
| 26   | Shear Spring            |
| 27   | Screw                   |
| 28   | Trigger Pin             |
| 29   | Pin                     |
| 30   | Brass Tube              |
| 31   | Stop Plate Spring       |
| 32   | Frame                   |
| 33   | Slide Release Button    |
| 34   | Triger                  |
| 35   | Trigger Link            |
| 36   | Grip                    |
| 37   | Grip Screw              |
| 38   | Slide Release lever     |
| 39   | Slide Stop              |
| 40   | Slide Stop Spring       |
| 41   | Magazine Release Button |
| 42   | Pin                     |
| 43   | Hammer Spring           |
| 44   | Hammer Spring Cover     |