MAVERICK SERIES PISTOL USER GUIDE


6MM PISTOL / GAS VERSION




KROWN LAND INTERNATIONAL CO., LTD.


www.krownland.com.tw sales@krownland.com.tw

MAVERICK PARTS DESCRIPTION





Loading BB Bullets



⚠WARNING

- ▲When using airsoft guns eye protection is required.(goggles or mask)
- ▲Never place your finger on the trigger until you are ready to fire the gun. Alway put the gun in safe mode when not in use. Tread every gun as if it is loaded.
- ▲Please keep away from children.
- ▲BBs may remain in the barrel after magazine removal. To avoid injury, never look directly into the barrel and ensure the gun is always pointed in safe direction.
- ▲Disassembly or modification of this product may result in damage to your Airsoft gun, loss of warranty, and/or serious injury.
- ▲Please select a safe place to fire your airsoft gun. Always know your state and local laws concerning airsoft gun use.
- ▲Do not aim or shoot at humans, animals, buildings, or vehicies.
- ▲Please use a firearm case or bag when transporting your airsoft gun.

GAS INJECTION


STEP 1



1.Press the Magazine Catch.

2.Remove the Magazine by pulling it downward.


STEP 2




1. Turn the Magazine upside down


2.Keeping the gas Valve inverted and vertical to the Magazine,inject gas until completely filled.

HOP-UP ADJUSTMENT




1. Push the Slide Realeas Lever to disassemb the Slide.
2. Pull the Slide backwards and hold.
3. Remove the Slide.






Use Allen Key adjust the Hop-Up.



MAVERICK SCHEMATIC GAS Ver.



Parts List

NO.	DESCRIPTION
M1	MAGAZINE LIP
M2	MAGAZINE RUBBER
M3	MAGAZINE FRAME
M4	VALVE
M5	MAGAZINE SEAL
M6	MAGAZINE BASE
M7	GAS VALVE
M8	PIN
M9	SPRING
M10	BB FOLLOWER
M11	SPRING GUIDE
M12	GAS TUBE

NO.	DESCRIPTION
A1	Air Nozzle
A2	Air Nozzle Base
1	SLIDE(57)
1-1	SLIDE(MAV)
2	SLIDE BASE
3	REAR SIGHT SET
4	BARREL FIXING RINGS
5	RECOLIL SPRING
6	BARREL
7	HOP UP BUCKING
8	HOP UP CHAMBER
9	HOP UP BUCKING BASE
10	RECEIVER FRAME(57)
10-1	RECEIVER FRAME(MAV)
11	TRIGGER SET
12	SLIDE LOCK
13	SLIDE CATCH
14	SAFTY LEVER-R
15	SAFTY LEVER-L
16	RAIL FIX
17	SLIDE RELEASE BUTTON
18	HAMMER SET
19	MAGAZINE CATCH
20	PIN-A
21	PIN-B
22	PIN-C